



New

T2

INSTALLATION AS EASY AS ...

1 - 2 - 3

WWW.TERMISCOPE.COM

INSTALLATION PROCEDURES

Step 1

Inspect thoroughly the property to find any active termite infestations, damage, or conditions favorable to future activity. Wherever possible, place stations every 10 -14 feet around the perimeter of the property (never more than 20 feet maximum) and about 2 feet away from the structure (3 feet away if a liquid termiticide has been applied). Also, whenever necessary due to random termite foraging, place stations near moisture sources: trees and stumps, woodpiles, wooden fences and decorative wood structures.

Step 2

Make the installation hole somewhat larger than the width and height of the station.

Step 3

Insert the station into the hole making sure the back-fill surrounds the entire station. This step is very important because it will help enhance the success of the transition by the termite into the station.

Note: The Visual Alert device should be moved or replaced if excessive moisture or fungus levels deter termites from feeding on the triggering mechanism.



TERMISCOPE UNIT READY
FOR INSTALLATION



INSTALLED IN GROUND



ACTIVATED TERMISCOPE
UNIT